

INSTRUCTIONS FOR USE

1. Assess the liquid that was spilt before applying any absorbent. Consult the spill products MSDS to assist in ensuring that all appropriate safety precautions are taken including the use of appropriate PPE equipment..
2. Contain the spill using the absorbent or containment sock.
3. Apply absorbent to cover spill.
4. The mix of absorbent and the spill should appear dry, if not, apply more absorbent until it looks dry.
5. Using a stiff broom, sweep absorbent over the spill area.
6. If the mix does not appear dry or there remains an oily film on the surface, apply additional absorbent.
7. Use pads to wipe clean any area or equipment not cleaned by the absorbent.
8. Dispose of in accordance with local government regulations.
9. Complete an incident report and file.
10. Re-stock kit with replacement stock.

CONTENTS

ES-SKB-30Y 30L Yellow Spill Kit Bag	1
ES-PPGP-400 Poly Pads GP - 48x43cm Heavy Weight - Dimpled & Perforated	5
ES-A-FS-05 FloorSweep 5kg bag	1
ES-SOGP-75-1.2 Grey Absorbent Socks - GP - 1.2m x 75mm	1
ES-G-NL Pair of Nitrile Gloves	1
ES-WB SpillSmart Contaminated Waste Bags - 450mm x 720mm	3
ES-DPB Dust Pan & Brush	1
ES-STGP Spill Kit Sticker	1
ES-SKIN Spill Kit Instructions	1

